

Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the Australian Standard AS 4685.1:2014.



K&K Hill slide (3,00) with starting platform 0,20

One-time maintenance

041870501

Check all solew connections, reagmen, il necessary.	approx. 4-5 weeks after installation					
Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Where appropriate, clean playing sand						
Check cleanliness of playing and safety area. Remove any foreign object						
Check cleanliness of sliding surfaces, remove protruding parts, exchange damaged sliding course coverings						
In case of drying cracks, remove splinters of wood and chamfer sharp edges						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

once,

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).