Instructions for maintenance

© 2010 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



0-21637-501 K&K Play structure

	One-time maintenance						
	Check all screw connections; if necessary screw down again.	one-time only approx. 4-5 weeks after installation					
	Recommendations about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
	Check cleanliness of play- and safety area, take out alien elements						
	Check stability of vertical posts, tighten bolt-connections if necessary						
	Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary						
	Check slide chutes for cleanliness, take out protruding elements, repair defect sliding sheet metal						
	In case of dry shakes remove splinters and brake chamfer edges						
X	Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.						

Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)