Instructions for maintenance

© 2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

0-32113-000 K&K Sand playtable



Recommendations	\$	thly	thly	>	>	>
about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check stability of vertical posts						
Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary						
Clean playsand/playbark						
Check foundation, foundation anchoring and whole construction for or decay, repair or replace if necessary.						
In case of dry shakes remove splinters and brake chamfer edges						

Please pay attention!

The mentioned maintenance intervals are a recommendation only. They have to be accommodated to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)