


Impact area
(approx. 17 m²)
Area which has to be covered with impact absorbing surfacing

Free height of fall = 0,95 m



1. Assign location of equipment considering the impact area/(falling) space requirements.
2. Excavate soil for ground anchor, according to drawing.
3. Put ground anchor into hole and align it.
4. Please note: To achieve maximum stability and a safe installation, it is necessary to cover the bottom plate of ground anchor with a reinforced (4x BS 500S /Ø10 mm x 1,50) concrete slab 0,50 x 1,70 x 0,10 made of compressed concrete C20/25 (acc. to drawing).
5. Cover up to the top of ground anchor with surfacing material which meets the requirements for impact attenuation so that the critical fall height of the surfacing is equal to or greater than the free height of fall of the equipment (according to EN 1176-1).
6. Due to forced movement, it is essential to cover the entire impact area with a surfacing material which meets the requirements for impact attenuation so that the critical fall height of the surfacing is equal to, or greater than, the free height of fall of the equipment (according to EN 1176-1).
7. Check all screw connections according to maintenance instructions after 4-5 weeks and retighten, if necessary. Please take care that all special tools (e.g. special Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.

